ADVENT

COLOR TELEVISION RECEIVER

INSTRUCTION MANUAL

Q2035A

Before operating the unit, please read this manual thoroughly.

PART 1 REMOTE CONTROLLER’ S OPERATION

ADVENT

Universal Remote Control

OWNER’ S MANUAL

CONTENTS

1. BATTERY INSTALLATION ····· 1
2. BUTTON INTRODUCTION ····· 1
3. HOW TO SET THE UNIT ····· 2
4. HOW TO GET THE CODE DISPLAY (3 DIGITS) ····· 2
5. HOW TO WORK WITH "QUICK SEARCH" ····· 2
6. HOW TO SWITCH OVER TO DIFFERENT DEVICE ····· 2
7. CODE LIST ON SETUP MODE OR QUICK SEARCH MODE ····· 2
8. MEMO OF BRAND & MODEL ····· 2
9. BRAND CODE LIST ····· 3

1. BATTERY INSTALLATION

Please install the batteries before you operate this remote control unit using the following steps.



Open the battery cover.



Install two "AAA" batteries matching the +/- polarities of the battery to the +/- marks inside the battery compartment.



Replace the battery cover.

Note:

Do not try to recharge batteries they are not intended to be recharged.

Use only the size and type of batteries specified. Do not mix different types of batteries together or old batteries with fresh ones.

When the remote control will not be used for a long period of time or when the batteries are worn out, remove the batteries.

Do not throw the batteries into a fire. Dispose of used batteries in the specified manner.

Do not drop, dampen or disassemble the remote control.

2. BUTTON INTRODUCTION


Indicator: The indicator lights up when any button is pressed
To program the remote or search through codes
To mute the sound
To select three digit position number
On-screen display
Sleep timer
To select STEREO, SAP or MONO
▲ ◄ ▼ ► : MENU control buttons
► ■ ◄◄ ►►: PLAY, STOP, REWIND, FFWD control buttons VCR/DVD/VCD
Turn On/Off the unit
To select products to be controlled with RC
To select to view program from external video equipment (VCR, DVD, VCD,etc.)
Direct channel selector
Quickly returns to previous selected channel
Access the main menu
Volume up/down
Access the Picture menu
Menu function demonstration
Record button for VCR
Closed Caption decoder/ Pause button for VCR/DVD/VCD
SET
MUTE
AV
SLEEP
DSP
MENU
PIC
STEREO
DEMO
CCD
ADVENT

3. HOW TO SET THE UNIT

Locate the correct code of the device's brand/model from the attached code list.
Key in the code to function the unit as follow:

1) Hold set then press any key of the following keys: TV, VCR, CAB/SAT, DVD/VCD/HIFI.
2) Enter code (3 digits)
3) The led will blinking two time.

* * After completion of the setting, if accurate, all the devices and functions can be controlled. Otherwise, the code may not be correct for your device. Please repeat the same process from steps 1) to 3) by entering other codes until getting the correct one for your device.

Note:

a) Do not exceed 5 seconds between each step.
b) There might be other codes than the correct code, which can also control some, but not all functions. Suggest always to locate the very exact code.

4. HOW TO GET THE CODE DISPLAY (3 DIGITS)

STEP1 Hold set then press 1 simultaneously, and release, the count of blinking represents the numeral of the 1st digit.
STEP2 Hold set then press 2 simultaneously, and release, the count of blinking represents the numeral of the 2nd digit.
STEP3 Hold set then press 3 simultaneously, and release, the count of blinking represents the numeral of the 3rd digit.

5. HOW TO WORK WITH "QUICK SEARCH"

In cast the code could not be located from the code list, please try quick search:
STEP1 Turn on the power switch of the controlled device.
STEP2 Press one device key that you want to control.
STEP3 Hold set 3 seconds then release and the **quick search** mode is on with the led blinking.
STEP4 If the on/off switch of controlled device has action. Press set immediately and release.

* After completion of the quick search, if accurate, all the devices and functions. can be controlled, otherwise, the code may not be the very correct one for your device. Please repeat step 1-4 until getting the correct code.

6. HOW TO SWITCH OVER TO DIFFERENT DEVICE

Press any key of the following keys: TV, VCR, CAB/SAT, DVD/VCD/HIFI to quit the first device mode.

7. CODE LIST ON SETUP MODE OR QUICK SEARCH MODE

DEVICE NAME	FOR DEVICE	TOTAL CODES	ACTIVE DEVICE CODE
TV	TV/CTV/TXT	290	001-290
VCR	VCR	255	001-255
CAB/SAT	CABEL/SATELLITE	186	001-186
DVD/VCD/HIFI	DVD/VCD/HIFI	240	001-240

8. MEMO OF BRAND & MODEL

Please fill the following form according to your device (including brand, model and code) so that you could quickly set the remote controller.

DEVICE	BRAND	MODEL	CODE
TV			
VCR:			
CAB/SAT:			
DVD/VCD/HIFI:			

9. BRAND CODE LIST

Brand	TV setting No.	VCR setting No	CATV/SAT setting No	DVD/VCD/HIFI setting No
ADVENT	001 002 133 134 142			
AUDIOVOX	026			
AIKO	026			
AIWA	039 058	111 114 136 025 031 051 085 096		021
AKAI	073 079 084 085 101 107 109 111 123 125	026 029 030 089 090 098 099 101 108 132 137		
ADMIRAL	143 146 147 148			
AUSTAR		117		
ANITECH		118 131		
AUTOVOX		119		
AMSTRAD			029 030 031 032 065 066 067 068 092	
ATRANTA			055	
ATLANTA			059	
ALOSTAY		113		
BAIRD		102		
BSR		108 134		
BT			074	
CGE	126 127 149 150			
CURTIS			001 006 055 059	
CABLEVIEW			011 014 017	
CITIZEN			011 014 017	
CINAL+			044 081	
DAEWOO	026 030 040 080 081 082 086 128 151 152	042 043 069		
DEHAN			019	
D-BOX			085	
DENON				018 061 062 107 108
DMTECH				096 050
DUAL-TEC		120		
EMERSON	030 137 143 153			
ELBE	089 130 103 154	100		
ECHOSTAR			026 041 042 043 045 078 079 080	
FERGUSON		104		
FINLUX	034 135 155 156 157			
FORCE			050 089	
FUNAI	057 059 060 158 159			
FIRSTLINE	136 160 161 162 163			
FISHER	088 164 165 166 167	095 103		
GRADIENTE	024 029 168 169 170			
GOLDSTAR	027 171 172 173 174		018	
GRUNDIG	028 077 175 176 177	055 070 071 091 092 093	033 069	016

GRANDA		094 110		
GI			002 004 020 082	
GALAXIS			035 049 088	
GI/JERROLD			056	
GOLDSTAR	027 178 179 180 181			
HITACHI	019 099 050 182 183	027 033 034		024 025
HISENSE	005 006 120 121			
HINARI		097 130		
HAMLIN			008 012 015 061	
HARMAN				063 109
INNOHT		105		
IRRADIO		082		
ITT-NOKIA	102 110 112 184 185			
JVC	011 012 032 033 045 066 095 186 187 188	014 015 022 044 048 049 052 053 054 077 078 079 080 115 116	038 039 074 075	006 017 047 048 051 054 060 064 065 093 094 097 100 106 110 111
JENSEN	001 002 133 134 142			
JERROLD			002 004 020 056 077 082	
KASEIKYOU	047 189 190 191 192			
KARDON				109 063
KATHREIN		036 037 072 073		
KENWOOD				008 029 030 031 032 039 043 066 075 076 078 085 089 112
LG	027 193 194 195 196	038	018	
LUXOR	125 197 198 199 200			
LOEWE	129 201 202 203 204	020 127		
LIDA				028 074
LG-GOLDSTAR	092 104 106 205 206	032 106 107		
MAGNAVOX	013 207 208 209 210		023 024	067 113
MASOOM			093	
MATSUI		056 057		013
MITSUBISHI	014 048 211 212 213	046 047 063		010 045 068 091 114
MIVAR	070 131 214 215 216			
MICROMEGA				009
MARANTZ		121		
MASPRO			036	
METZ	132 217 218 219 220 221			
NAKKO	026 222 223 224 225 226			
NEC	029 056 227 228 229 230	074 075		
NOBLEX	031 231 232 233 234 235			
NORDMENDE		083		
NOKIA	035 036 236 237 238		087	

	239			
OPTA	129 240 241 242 243 244			
ORION		028 084 112 135		044 059 088 090 105 120
OAK			005 013 058	
OPTIMUS				004
ONKYO				022 067 069 113 115
PANASONIC	015 020 046 047 061 062 078 096 097 122 245 246	021 023 060 061 062	009 010 040 062 063 076	002 018 019 020 052 061 098 107
PHILCO	026 030 247 248 249 250			
PHILIPS	013 072 124 251 252 253 254 255 256 257 258 259	011 012 013 016 017 018 058 059	034 047 070 084	023 070 113 116
PEONY	038 042 260 261 262 263			
PIONEER	055 264 265 266 267 268	086	003 057	034 041 080 087
PRIMESTAR			025	
PRIMA	001 002 133 134 142			
PHONOTREND			035	
PACE			052	
PROSCAN				071
RFT			035	
RCA	068 269 270 271 272 273		009 010 021 062 063	071 117
REGAL			015 061	
RRADIO		109		
SHARP	016 054 063 274 275 276	024 064		026
SONY	017 049 069 098 277 278 279 280 281 282 283 284	001 002 003 004 005 006 007 008 009 010	022	001 054 055 101
SAMSUNG	021 037 038 071 094 285	039 040 041 045 057	003 016 027	011 014 015 049 095
SANYO	022 025 052 053 064 090 108 138 139 140 286 287	035 036 067 068 134		007 033 040 056 057 079 086 102 103
SEARS	064 288 289 290			
SINUDYNE	074 075 076 091			
SELECO	087 105			
SINUDYNE		087 088		
SIGMA			005 013 058	
SATLANTA			001 006	
SL MARX			016	
SKY			028 064	

SKYMASTER			035 071	
SAGEM			046	
SELECTOR			090	
SAST				027 073
SHERWOOD				118 072
TOSHIBA	018 023 051 065 100	037 050 065 081		003 005 031 042 053 058 059 067 077 088 099 104 105 113
TEKNIKA	026			
THOMSON	067 083 093	019 050 066 072 073 076 123 124 125 126	019	012 046 092
TOBO	119			
THORN		104 122		
TAIHIN				
TPS			046 083	
TRIAX			051 054 091	
TECHNICS				004 061 107
VIDEOWAY				060
WANLIDE				119
YAMAHA	145			035 036 037 038 061 081 082 083 084 107
ZENITH	026 030 143 144		007 060	067 113

PART 2 TELEVISION OPERATIONS

Contents

Important safety instructions-1

Identification of Controls-------3

Front ----------3
Back----------4
Remote Controller ----------5
Installing batteries ----------6
Effective range of the Remote----------6

Installation ----------7

Antenna installation ----------7
Connecting video and audio equipment ---------8

Turning on/off ----------9

Turning on ----------9
Turning off ----------9

Select Input Signal ----------10

Watching AV program ----------10
Switching from AV to TV----------10

Tuning in----------11

To enter the TUNING menu ----------11
Auto Search ----------11
Erasing an unnecessary channel ----------12
Fine tuning ----------12
Setting the TV/CATV option ----------13
Setting the Color System----------13

Channel Selection ----------14

Adjusting Picture ----------15

To enter the PICTURE menu----------15
Adjusting picture----------15
Setting Blue background option ----------16
Setting Noise Reducer option ----------16

Sound Control ----------17

Timer Setting----------18

To enter the TIMER menu----------18
Setting the Clock ----------18
Setting Sleep timer ----------18
Setting the Off Time ----------19
Setting the On Time ----------19

System Setting ----------20

To enter the SET UP menu ----------20
Selecting OSD language ----------20
Setting Menu Demo ----------20
Setting Closed Caption(CCD)----------21
Selecting audio mode ----------21
Recalling the On-screen display ----------21

Parental Control----------22

Child lock----------22
To enter Child lock submenu ----------22
Setting Child lock----------22
Changing the password ----------22
Setting V-chip----------23
To enter the V-chip menu ----------23
MPAA RATING SET-UP ----------23
TV RATING SET-UP ----------24
Setting individual Content Categories for TV Rating ----------25
CANADIAN ENGLISH RATING SET-UP-------25
CANADIAN FRENCH RATING SET-UP -------26
CHANGING THE PASSWORD----------26

Troubleshooting Guide --------27

Specifications----------29

Important safety instructions

CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER(OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

Before using the unit, be sure to read all operating instructions carefully. Please note that these are general precautions and may not pertain to your particular unit. For example, this unit may not have the capability to be connected to an outdoor antenna.

1. READ INSTRUCTIONS
All the safety and operating instructions should be read before the product is operated.

2. RETAIN INSTRUCTIONS
The safety and operating instructions should be retained for future reference.

3. HEED WARNINGS
All warnings on the product and in the operating instructions should be adhered to.

4. FOLLOW INSTRUCTIONS
All operating and use instructions should be followed.

5. CLEANING
Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. ATTACHMENTS
Do not use attachments not recommended by the product's manufacturer as they may cause hazards.

7. WATER AND MOISTURE
Do not use this product near water (a bathtub, washbowl, kitchen sink, laundry tub, wet basement, or swimming pool for example)

PORTABLE CART WARNING
(symbol provided by RETAC)

S3126A

8. ACCESSORIES
Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product. Any mounting of the product should follow the manufacturer' s instructions and should use a mounting accessory recommended by the manufacturer.

8A. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

9. VENTILATION
Slots and openings in the cabinet and in the back or bottom are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat source. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

10. POWER SOURCES
This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

11. GROUNDING OR POLARIZATION
This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

12. POWER-CORD PROTECTION
Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

13. LIGHTNING

To protect your product from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

14. POWER LINES

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching power lines or circuits as contact with them might be fatal.

15. OVERLOADING

Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

16. OBJECT AND LIQUID ENTRY

Never push objects of any kind through openings in the product as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid on the product.

17. OUTDOOR ANTENNA GROUNDING

If an outside antenna is connected to the product, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electric Code, ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge product, size of grounding conductors, location of antenna discharge product, connection to grounding electrodes, and requirements for grounding electrodes.

18. SERVICING

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

19. REPLACEMENT PARTS

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

20. SAFETY CHECK

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

21. WALL OR CEILING MOUNTING

The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

22. DAMAGE REQUIRING SERVICE

Unplug the product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

a. When the power-supply cord or plug is damaged.
b. If liquid has been spilled, or objects have fallen into the product.
c. If the product has been exposed to rain or water.
d. If the product does not operate normally after installation by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
e. If the product has been dropped or the cabinet has been damaged.
f. When the product exhibits a distinct change in performance.

23. HEAT

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

24. NOTE TO CATV SYSTEM INSTALLER

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.



EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE

WARNING: FOR CONTINUED SAFETY, REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S RECOMMENDED PARTS (REFER TO SERVICE LITERATURE).

Identification of Controls

Front



1.🎧 :Earphone Jack
AV input terminals (VIDEO, AUDIO L,R)
2. TV/AV button: video input select.
3. MENU button: to enter into menu operation.
4. VOL- button: volume down adjust; menu item adjust.
5. VOL+ button: volume up adjust; menu item adjust.
6. CH- button: channel down select; menu item select.
7. CH+ button: channel up select; menu item select.

Back



1. Antenna input
2. DVD input (Y, C_B , C_R , AUDIO L, R)
3. AV input (VIDEO, AUDIO L, R)
4. S-VIDEO input

Notes:

The S-VIDEO terminal is prior to the VIDEO terminal, if you want to watch video program from the VIDEO input terminal, please disconnect the S-VIDEO first.

Identification of Controls(continued)

Remote Controller



Indicator: the indicator lights up when any button is pressed

To mute the sound

To select three digit position number

On-screen display

Channel up/down
Menu item select

Sleep timer

To switch between STEREO, SAP or MONO

▲◄ ▼ ►: MENU control buttons

Turn On/Off the the unit

To select to view program from external video equipment (VCR, DVD, VCD,etc.)

Direct channel selector

Quickly returns to previous selected channel

Access the main menu

Volume up/down
Menu item adjust

Access the Picture menu

To start/stop Menu demonstration.

Closed Caption
decoder channel select

Important:

If your remote controller does not work correctly, maybe the setting of the remote controller is wrong, please try the following steps.

1. Press and hold the SET button, followed by the TV button at the same time until the indicator lights up.

2. Press 1, 3, 3 buttons one by one. As a response, the indicator of the remote control will twinkle twice, otherwise please repeat the above 2 steps.

Notes:

In MENU operations, the function of the ▲/▼ buttons is equal to the CH+/- buttons; and the function of the ►/◄ buttons is equal to the VOL+/- buttons.

Installing batteries







Notes:

- Do not try to recharge batteries they are not intended to be recharged.
- Use only the size and type of batteries specified. Do not mix different types of batteries together or old batteries with fresh ones.
- When the remote control will not be used for a long period of time or when the batteries are worn out, remove the batteries.
- Do not throw the batteries into a fire. Dispose of used batteries in the specified manner.
- Do not drop, dampen or disassemble the remote control.

Effective range of the Remote



Notes:

- When there is an obstacle between the TV and the transmitter, the transmitter may not operate.
- When direct sunlight, and incandescent lamp, fluorescent lamp or any other strong light shines on the REMOTE SENSOR of the TV, the remote operation may be unstable.

Installation

INSTALL the unit in a room where direct light will not fall upon the screen. Total darkness or a reflection on the picture screen may cause eyestrain. Soft and indirect lighting is recommended for comfortable viewing.

Antenna installation

Optimum reception of colour requires a good signal and will generally mean that an outdoor antenna must be used. The exact type and position of the antenna will depend upon your particular area.



Notes:

- It is recommended that the 75-ohm coaxial cable be used to eliminate interference and noise which may occur due to radio wave conditions.
- The antenna cable should not be bundled with the power cord and the like.

Connecting video and audio equipment

This TV set provides 2 groups of AV input terminals including one Video (S-Video) and one group of DVD input terminals for your convenient connection to VCR, DVD or other video equipment. To enjoy the high quality picture.
Please refer to the **owner's manual** of the equipment to be connected as well.

Important notes on the AV input terminals
Please do not use the side and rear AV input terminals at the same time.



You can also use the AV and DVD input terminals on the TV set rear as follows.



Ⓨ Yellow (video)
Ⓦ white (audio L)
Ⓡ red (audio R, C_R)
Ⓖ Green (Y)
Ⓑ Blue (C_B)

You can also use the S-VIDEO terminal if your video equipment has S-VIDEO.

Turning on/off







Turning on

1 **Insert the AC plug (with the 2 blades) into a conveniently located AC outlet having 120V, 60Hz.**

If no picture appears and the red indicator lights up, then the TV set is in STANDBY mode. Now please follow step 2.

Notes:

The AC plug supplied with the unit is polarized to help minimize the possibility of electric shock. If the AC plug does not fit into a nonpolarized AC outlet, do not file or cut the wide blade. It is the user's responsibility to have an electrician replace the obsolete outlet.

To prevent electric shock, do not use a (polarized) plug with an extension cord receptacle or other outlet unless the blades can be fully inserted.

2 **In STANDBY mode, press the power button on the TV set or on the remote controller and the TV set is turned on.**

Now the red and green indicator lights up, and the picture appears on the screen.

Notes:

In STANDBY mode, you can also turn on the set by pressing the **TV/AV, CH+/-** or **VOL+/-** button on the set's panel.
If there is no input signal, then a blue background appears.

Turning off

1 **Press the Power button on the remote controller or on the TV set to turn off the TV set.**

Notes:

The TV set can turn off automatically by:
A. **Sleep** timer function (needs to be set in advance).
B. **OFF** timer function (needs to be set in advance).

Select Input Signal





Watching AV program

This TV set provides 2 groups of AV input terminals including one Video (S-Video) and one group of DVD input terminals for your convenient connection to VCR, DVD or other video equipment.

1 Press TV/AV button on the TV set or AV button on the remote controller.

When the set is in TV mode, press this button and the set goes to AV mode and the "**Video**" ("**S-Video**") appears on the screen. Now you can watch video programs from AV input terminals.

2 Press TV/AV button on the TV set or AV button on the remote controller again to watch DVD program.

Now the "DVD" appears on the screen and you can watch DVD programs from DVD input terminals.

TV → VIDEO (S-VIDEO) → DVD

Switching from AV to TV

When the TV set is in AV mode, there are four ways for you to switch back to TV mode as follows.

1 Press TV/AV button on the TV set or AV button on the remote controller.

In VIDEO (S-VIDEO) input mode, press this button twice and go to TV mode; In DVD input mode press this button once and go to TV mode.

2 Press digit buttons to switch back to TV mode.

3 Press CH+ or CH- button to switch back to TV mode.

4 Press the ⇆ button to switch back to TV mode.

Tuning in







To enter the TUNING menu



- **Press MENU button.**
- **Press VOL+ or VOL- button to select Tuning icon**
- **Press CH- button to display the TUNING menu.**

Auto Search

Please enter the **TUNING** menu first.

1 **In TUNING menu page, press CH+ or CH- button repeatedly to highlight Auto Search item.**

2 **Press VOL+ button to start Auto Search.**

All active channels will be preset and stored into the memory automatically. After presetting, the TV will go to the channel before the **Auto Search** starts.

Notes:

During the process of **Auto Search**, pressing the **VOL-** button will stop the process and the TV will reture to the original channel before **Auto Search** started.









Erasing an unnecessary channel

Please enter the **TUNING** menu first.

1 **Press CH+ or CH- button repeatedly to highlight Channel item.**

2 **Press VOL+ or VOL- button to select a channel number (for example, channel10)**

3 **Press CH+ or CH- button repeatedly to highlight Add/Erase item.**

4 **Press VOL+ or VOL- button to set to Erase.**

Now channel 10 will be skipped when you browse channels by **CH+** or **CH-** button.

To restore a skipped channel, please use digit buttons to select the skipped channel, then repeat the above steps 3 and 4 and set the **Add/Erase** item to **Add**.

Fine tuning

Fine tuning is unnecessary under normal conditions. However, in areas of inferior broadcast conditions where adjustment is necessary for a better picture and sound, use Fine tuning.

Please enter the **TUNING** menu first.

1 **Press CH+ or CH- button repeatedly to highlight Channel item.**

2 **Press VOL+ or VOL- button to select a channel number you want to Fine tune (for example, channel10).**

3 **Press CH+ or CH- button repeatedly to highlight Fine item.**

4 **Press VOL+ or VOL- button to fine tune till the best possible picture and sound are obtained.**



Notes about AFT item:

The **AFT** can be set to **On** or **Off.** When the **AFT** is set to **On,** the TV set will automatically tune the program frequency to provide the best possible picture and sound.

Tuning in(continued)





Setting the TV/CATV option

Please enter the **TUNING** menu first.

1 Press CH+ or CH- button repeatedly to highlight TV/CATV item.

2 Press VOL+ or VOL- button to select TV or CATV.

In TV mode, the set receives antenna signals. In CATV mode the set receives Cable TV programs. Please select:
TV: If using VHF/UHF antenna.
CATV: If using Cable TV.

Setting the Color System

If the picture color is abnormal, maybe the color system setting is wrong. You can select a proper color system as follows.

Please enter the **TUNING** menu first.

1 **Press CH+ or CH- button repeatedly to highlight Color System item.**

2 **Press VOL+ or VOL- button to select a proper color system.**

The color system switches between **AUTO, NTSC358** and **NTSC443**.



Channel Selection





Before you select a channel, please select TV or CATV input signal. Please see the section of "To set the TV/CATV option ".
When you select TV, only channels received on antenna can be selected;
When you select CATV, channels received on cable can be selected.

1 Use Direct Channel Selector (0-9 and --- buttons)

To select one-digit channel:

- Press 0-9 digit buttons and wait for 2 seconds. For example, you need channel 5, please input "5" button and the screen displays "5-", the TV set goes to channel 5 in 2 seconds

To select two-digit channel:

- Press two digit buttons in order to input the channel number. For example, you need channel 10, please input "1" button, followed "0" button and the set goes to channel 10. **Be sure that the second press should be within 2 seconds.**

To select three-digit channel:

- Press "---" button to display "1--".
- Press two digit buttons in order to input the channel number. For example, you need channel 110, please input "1" button, followed "0" button and the set goes to channel 110. **Be sure that the second press should be within 2 seconds, otherwise, the set goes to channel 11.**

2 Use CH+ or CH- button

Press **CH+** button, the channel number increases;
Press **CH-** button, the channel number decreases.

3 Use previous channel ⇆ button

Press this button to switch between the current channel and the previous channel.

Adjusting Picture



To enter the PICTURE menu



- **Press MENU button.**
- **Press VOL+ or VOL- button to select PICTURE icon.**
- **Press CH- button to display the PICTURE menu.**



Adjusting picture

Please enter the **PICTURE** menu first.

1 Press CH+ or CH- button to select item.

2 Press VOL+ or VOL- button to adjust.

Item	VOL-	VOL+
Contrast	weaker	stronger
Brightness	darker	lighter
Color	paler	deeper
Sharpness	softer	sharper
Tint	purplish	greenish

There are three preset picture modes (**Sports, Standard** and **Movie**) and one user-set picture mode (**Personal**).
The adjusted settings are stored in **Personal**.

Item	Picture mode		
	Sports	Standard	Movie
Contrast	100	75	50
Color	70	60	50
Brightness	70	70	65
Sharpness	50	50	50

Notes:

You can quickly access the **PICTURE** menu by pressing the **PIC** button on the remote controller, and then repeat steps 1, 2 to adjust.



Setting Blue background option

Please enter the **PICTURE** menu first.

1 **Press CH+ or CH- button to select Blue Back item.**

2 **Press VOL+ or VOL- button to select On or Off.**

If the **Blue Back** is set to **On**, the TV set will display a blue background when there is no input signal.

Setting Noise Reducer option

Please enter the **PICTURE** menu first.

1 **Press CH+ or CH- button to select Noise Reducer item.**

2 **Press VOL+ or VOL- button to select On or Off.**

This function is useful when the picture is snowy because of a poor signal.
If the **Noise Reducer** is set to **On**, the picture will be improved.





Sound Control



1 Use VOL+ or VOL- button.

Press VOL+ button, the volume increases;
Press VOL- button, the volume decreases.
The minimum volume is 0 and the maximum volume is 100.

2 Use MUTE button.

If you want to mute the sound, press **MUTE** button on the remote.

To resume the sound, press this button again.



Notes:

You can also resume the sound by pressing **VOL+** or **VOL-** button.

Timer Setting



To enter the TIMER menu



- **Press MENU button.**
- **Press VOL+ or VOL- button to select TIMER icon.**
- **Press CH- button to display the TIMER menu.**

Setting the Clock

Please enter the **TIMER** menu first.

1 Press CH+ or CH- button to select Clock item.

2 Press VOL+ or VOL- button to set the current time.

Notes:

We recommend you to set the current time before setting the **Off Time** or **On Time**.
If you disconnect the AC plug, the time will lost and the **Off Time** and **On Time** will not work. You need to set these items after you re-connect the AC plug.



Setting Sleep timer

You can quickly set the sleep timer by using the **SLEEP** button on the remote controller. With every press of this button the sleep time changes as follows:

OFF → 120 Min. → 110 Min. ⋯⋯ → 20 Min. → 10 Min.

For example, you would like the TV to auto turn off in 60 minutes, you can press the **SLEEP** button repeatedly till the screen displays as the right figure.
If you want to cancel the sleep timer, you can press the **SLEEP** button repeatedly till "**Off**" displays on the screen.



Notes:

When there is no input signal for 15 minutes, the TV set auto goes to STANDBY mode.

Timer Setting(continued)

Notes about On Time function:

When the set is turned on automatically at the preset time, if there is no operation to the set within 2 hours, the set will regard this as no one is watching. For the sake of power saving, the TV set will go to STANDBY mode automatically.





Setting the Off Time

Please enter the **TIMER** menu first.

1. **Press CH+ or CH- button to select Off Time item.**
2. **Press VOL+ or VOL- button to select Once or Every.**
3. **Press CH- button.**
4. **Press VOL+ or VOL- button to set the OFF time, for example PM 10:00.**

   The set auto turns off when the time is PM 10:00. If you set the **Off Time** item to **Once**, this function only effects once; If you set the **Off Time** item to **Every,** this function effects every day. To cancel this function, please set the **Off Time** to **Off**.

Notes:

The Time can not be accessed until you set the **Off Time** to **Once** or **Every**. When you are setting the time by VOL+/- button, if you press and release within 0.7 second, the time's increase or decrease step is 1 minute; if you press and hold for more than 0.7 second, the time's increase or decrease step is 10 minutes.

Setting the On Time

Please enter the **TIMER** menu first.

1. **Press CH+ or CH- button to select On Time item.**
2. **Press VOL+ or VOL- button to select Once or Every.**
3. **Press CH- button.**
4. **Press VOL+ or VOL- button to set the ON time, for example PM 6:00.**
5. **Press CH- button to select CHANNEL item.**
6. **Press VOL+ or VOL- button to select a channel number, for example, channel 10.**
7. **Press CH- button to select TV/CATV item.**
8. **Press VOL+ or VOL- button to select TV or CATV.**

   The set auto turns on and goes to channel 10 when the time is PM 6:00. If you set the **On Time** item to **Once**, this function effects only once; If you set the **On Time** item to **Every,** this function effects every day. To cancel this function, set the **On Time** item to **Off**.

Notes:

The Time can not be accessed until you set the **On Time** to **Once** or **Every**. When you are setting the time by VOL+/- button, if you press and release within 0.7 second, the time's increase or decrease step is 1 minute; if you press and hold for more than 0.7 second, the time's increase or decrease step is 10 minutes.

System Setting



To enter the SET UP menu



- **Press MENU button.**
- **Press VOL+ or VOL- button to select SET UP icon.**
- **Press CH- button to display the SET UP menu.**

Selecting OSD language

Please enter the **SET UP** menu first.

1 Press CH+ or CH- button to select an OSD language.

2 Press the VOL+ button to confirm.

There are three OSD languages in this TV set: English, French and Spanish.

Setting Menu Demo



Please enter the **SET UP** menu first.

1 Press CH+ or CH- button to select Menu Demo item.

2 Press the VOL+ or VOL- button to start.

Then the TV set starts menu demonstration. This function teaches you how to operate the menu.

Notes:

You can quickly start menu demonstration by using the **DEMO** button on the remote controller. When you press the **DEMO** button and wait for 2 seconds, the TV set starts menu demonstration.



System Setting(continued)







Setting Closed Caption(CCD)

Please enter the **SET UP** menu first.

1 Press CH+ or CH- button to select Closed Caption item

2 Press the VOL+ or VOL- button to select.

You can select the caption data channel (**C1/C2/C3/C4**), the text service channel (**T1/T2/T3/T4**) or turn off the Closed Caption (**Off**).

You can also quickly access the **Closed Caption** menu by pressing the **CCD** button on the remote controller.

Notes:

1.Some TV programs may not be broadcast with closed caption signals, and therefore, the TV will not be able to display captions. Also, text information is not offered by all stations.
2.Some TV programs only provide one channel caption, one channel text , or only caption without text.

Selecting audio mode

If the program you are watching is "STEREO" or "SAP", you can select audio mode by using the **STEREO** button on the remote controller. The audio mode changes as follows.

MONO ⟷ STEREO (If the program is **STEREO**)

MONO ⟷ SAP (If the program is **SAP**)

MONO → STEREO → SAP (If the program is **STEREO & SAP**)

Recalling the On-screen display

You can press the **DSP** button on the remote controller to recall the On-screen display.
First press of the **DSP** button displays the channel number and audio mode; before the display disappears, pressing **DSP** button again will display the time. To cancel the on-screen display, press the **DSP** button again or wait for 15 seconds.



Parental Control

Child lock







To enter Child lock submenu

Please enter the **SET UP** menu first.

- **Press CH+ or CH- button to select Child lock menu item.**
- **Input the password to enter into Child lock menu.**
  The default password to enter Child lock menu is **0000** and you can change it after you enter into Child lock submenu as the right figure.



Setting Child lock

Please enter the **Child lock** submenu as described above.

1. **Press CH+ or CH- button to select Channel item.**
2. **Press VOL+ or VOL- button to select a channel you want to lock. For example, channel 10.**
3. **Press CH+ or CH- button to select TV/CATV item.**
4. **Press VOL+ or VOL- button to select TV or CATV.**
5. **Press CH+ or CH- button to select Child lock item.**
6. **Press CH+ or CH- button to select On.**
   Now the **Child lock** is active. When you select channel 10, a blue background appears and the note as "**Notice: child lock function active**" also appears when there is no OSD display on the screen**.** To turn off the **Child lock** function, please select **Off.**

Changing the password

Please enter the **Child lock** submenu as described above.

- **Press CH+ or CH- button to select New password item.**
- **Input a new password by using 0-9 digit buttons. Press MENU button to confirm after you finish inputting the new password.**



Important:

Be sure to write down the new password and retain it for future use because you can not access the Child lock submenu if you input an incorrect password.
If you forget the password, please input **4,3,2,1** in order and you can also enter into the Child lock submenu.

Parental Control(continued)

Setting V-chip





To enter the V-chip menu

Please enter the **SET UP** menu first.

1 **Press CH+ or CH- button to select Vchip password item.**

2 **Use digit buttons (0-9) to enter the password(the preset password is 0000).**

IMPORTANT: This password can be changed after the original password is entered.



Note: To enable V-chip setting, you should set *BLOCK* to *ON* in V-chip menu.



MPAA RATING SET-UP

Rating guidelines are provided by broadcast stations. Most television programs and television movies can be blocked by TV Rating and/or Individual Categories. Movies that have been shown at the theaters or direct-to-video movies use the Movie Rating System (MPAA) only.

Please enter the V-chip menu first.

1 **Press CH+ or CH- button to select MPAA RATING item.**

2 **Press VOL+ or VOL- button to enter into MPAA RATING sub-menu.**

3 **Use CH+ or CH- to select the desired rating.**

4 **Press VOL+or VOL- button to block the rating (" ↑ " will appear), or unblock (" IGNORE " will appear).**



Movie Ratings:
* Unblocked
* G and Above (general audience)
* PG and Above (parental guidance suggested)
* PG-13 and Above (13 years and up)
* R and Above (restricted)
* NC-17 and Above (18 years and up)
* X (adult)

V-Chip enables parents to prevent their children from watching inappropriate material on TV. V-Chip reads the ratings for programming (except for news, sports, unedited movies on premium cable and Emergency System signals), then denies access to programming if the program's rating meets the limitations you select. In this case, the program will be blocked.





TV RATING SET-UP

TV Parental Guidelines may have one or more letters added to the basic rating to let parents know when a show contains higher levels of violence, sex, adult language or suggestive dialogue:

Please enter the V-chip menu first.

1 **Press CH+ or CH- button to select TV PARENTAL GUIDELINES item.**

2 **Press VOL+ or VOL- button to enter into TV PARENTAL GUIDELINES sub-menu.**



3 **Use CH+ or CH- to select the desired rating.**

4 **Press VOL+ or VOL- to block the rating (" ↑ " will appear), or unblock (" IGNORE " will appear).**

TV Ratings:
* Unblocked
* TV-Y andAbove (all children) (individual content categories do not apply)
* TV-Y7 (7 years and up)
* TV-G and above (general audience) (individual categories do not apply)
* TV-PG andAbove (parental guidance suggested)
* TV-14 and above (14 years and up)
* TV-MA (mature audience)

Content Categories:

* F Violence: fantasy violence	(applies only to TV-Y7)
* Violence	(applies to TV-PG and above, TV-14 and Above, TV-MA)
* Sex scenes: sexual situations	(applies to TV-PG and above, TV-14 and Above, TV-MA)
* Language: adult language	(applies to TV-PG and above, TV-14 and Above, TV-MA)
* Dialog: sexual dialogue	(applies to TV-PG and Above, TV-14)

Parental Control(continued)

Setting V-chip





Setting individual Content Categories for TV Rating

Please enter the TV PARENTAL GUIDELINES sub-menu first.

1 **Press CH+ or CH- button to select CONTENT item.**

2 **Press VOL+ or VOL- button to enter into the CONTENT menu.**



3 **Press CH + or CH- button to select a TV Rating.**

4 **Press VOL + button to enter into content categories menu.**

5 **Press CH+/- button to select content category.**

6 **Press VOL + button to set Block or View. If the content category does not apply to the TV rating, - - - will be displayed.**

7 **Press VOL - button to exit content categories menu.**

Notes:

If you want to exit the menu, please press MENU button repeatedly.

CANADIAN ENGLISH RATING SET-UP

Please enter the V-chip menu first.

1 **Press CH+ or CH- button to select CANADIAN ENGLISH RATING item.**

2 **Press VOL+ or VOL- button to enter into CANADIAN ENGLISH RATING sub-menu.**



3 **Press CH+ or CH- to select the desired rating.**

4 **Press VOL+ or VOL- to either block the rating ("↑" will appear), or unblock (" IGN ORE " will appear).**



Canadian English Language Ratings:
* E: Exempt.
* C: Children.
* C8+: Children 8 years and older.
* G: General programming, suitable for all audiences.
* PG: Parental guidance.
* 14+: Viewers 14 years and older.
* 18+: Adult programming.





CANADIAN FRENCH RATING SET-UP

Please enter the V chip menu first.

1 **Press CH+ or CH- button to select CANADIAN FRENCH RATING item.**

2 **Press VOL+ or VOL- button to enter into CANADIAN FRENCH RATING sub-menu.**



3 **Press CH+ or CH- to select the desired rating.**

4 **Press VOL+ or VOL- to block the rating (" ↑ " will appear), or unblock (" IGN ORE " will appear).**

Canadian French Language Ratings:
* E: Exempt.
* G: Children.
* 8 ans+: Children 8 years and older.
* 13 ans+: Children 13 years and older.
* 16 ans+:Viewers 16 years and older.
* 18 ans+: Adult programming.

CHANGING THE PASSWORD

Please enter the V-chip menu first.

1 **Press CH+ or CH- button to select NEW password item.**

2 **Input a new password by using 0-9 digit buttons. Press MENU button to confirm after you finish inputting the new password.**



Next when you want to enter the V-chip menu, you should use this new password. Make sure to remember the password.

Troubleshooting Guide

Check the following before requesting service.

	SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Power	No power	The AC power cord is not connected.	Connect the AC power cord to the AC outlet
TV broadcast reception	Poor or no picture.	TV station experiencing problems.	Try another channel.
		Picture control is not adjusted.	Check picture control adjustments.
		Possible local interference.	Check for source of reception disturbance
		Antenna/CATV connector is not connected.	Check CATV connection or VHF/UHF ant.
	Picture wobbles or drifts.	TV station experiencing problems.	Try another channel.
		Cable TV channel is scrambled.	A Cable box needs to be used (if desired).
		Possible local interference.	Check for source of reception disturbance
	No CATV reception.	CATV connected or not connected.	Check all CATV connections.
		TV/CATV set to TV.	Set TV/CATV to CATV
		Cable TV service interrupted.	Contact your Cable TV company.
	No reception above CH13.	TV/CATV set to TV.	Set TV/CATV to CATV.
	Poor or no sound.	TV station experiencing problems.	Try another channel.
		MUTE button is pressed.	Press MUTE button again.
		Possible local interference.	Check for source of reception disturbance.
		Antenna/CATV connector is not connected.	Check CATV connection or VHF/UHF ant.
		Volume is set to minimum.	Increase volume.
	TV Shuts off.	Sleep Timer is set.	Set Sleep Timer to "Off".
		Off Timer is set.	Clear Off Timer.
	Closed Captioning not working.	TV Signal is weak.	Check CATV or VHF/UHF antenna.
		TV station experiencing problems or program tuned is not closed captioned.	Try another channel.
		Closed Captioning not turned on.	Press the CCD button.
Remote Control	Remote control does not operate.	The remote control is not aimed at the sensor.	Aim the remote control at the Remote sensor.
		Distance is too far or too much light in the room.	Operate within 23 feet or reduce the light in the room.
		There is an obstacle in the path of the beam.	Clear the path of the beam.
		The batteries are weak.	Replace the batteries.
		The batteries are not inserted correctly.	Insert correctly.
V-CHIP	Parental Control not Working properly.	Block item is set to "Off".	Set the block item "On".
		News or sports event being broadcast.	Parental Control does not work with News or sporting events.
		Ratings not set.	Set ratings as desired.

RECEPTION DISTURBANCES

Most types of television interference can be remedied by adjusting the height and position of the VHF/UHF antenna. Outdoor antennas are recommended for best results if not using cable or a satellite. The most common types of television interference are shown below. If one of these symptoms appear when the TV is connected to a Cable TV system, the disturbance may be caused by the local cable company broadcast.

IGNITION:

Black spots or horizontal streaks may appear, picture may flutter or drift. Usually caused by interference from automobile ignition systems, neon lamps, electric drills and other electric appliances.

GHOSTS:

Ghosts are caused by the television signal following two paths. One is the direct path and the other is reflected from tall buildings, hills or other objects. Changing the direction or position of the antenna may improve the reception.

SNOW:

If your receiver is located in the fringe area of a television station where the signal is weak, your picture may be marred by the appearance of small dots. When the signal is extremely weak, it maybe necessary to install an external antenna to improve the picture.

RADIO FREQUENCY INTERFERENCE:

This interference produces moving ripples or diagonal streaks, and in some cases, causes loss of contrast in the picture.

PICTURE SIZE VARIATION:

A slight picture size variation is quite normal when you adjust the CONTRAST or BRIGHTNESS setting.

CARE AND MAINTENANCE

To prevent fire or shock hazard, disconnect your unit from the AC power source when cleaning. The finish on the receiver may be cleaned with a dust cloth and cared for as other furniture. Use caution when cleaning and wiping the plastic parts. Mild soap and a soft, damp cloth may be used.

Specifications

Power Supply:	AC 120V, 60Hz
Power Consumption:	70W
Dimensions:	24.1(W) × 18.3(H) × 18.7(D) inch
Weight(kg/lb):	23 kg/51 lb
CRT:	20" FLAT SCREEN
Audio Output:	2W × 2

Receiving channel:

VHF	2-13
UHF	14-69
CATV	2-69, (A-6)-(A-1), A-W, (W+1)-(W+28)
Total	181 channels

Color System:

Television: NTSC-M
AV: NTSC3.58/4.43, PAL 4.43

Antenna Impedance:	VHF/UHF 75 ohm
Accessories:	Remote controller × 1

Design and specifications are subject to change without notice.